

Extend Analog Audio.



the Audio extender

Extends your Audio up to 1000 feet from your Computer.

How it works

The Audio Extender sender unit sits next to your audio source. Stereo cables supplied with the Audio Extender package connects your audio source to the sender. The receiver unit connects to your speakers or audio output device. One CAT-5 cable connects the sender and the receiver to each other - up to 1000 feet away.

Package Includes:

- Audio Extender S Sender Unit
- Audio Extender R Receive Unit
- 6 foot audio cable
- 5V external power supply

Features:

- One CAT-5 cable used for extension
- Installs in seconds

Specifications:

- Sample Rate: 5 kHz (min) - 48 kHz (max)
- Frequency Response: 20Hz - 20kHz
- Interfaces: 1 x audio - line-out/headphones - mini-phone stereo 3.5 mm - 1
- Power Supply: 5 VDC (External)
- Dimensions: 1"H x 1"W x 4"D
- Shipping Weight: 3 lbs.

